

LARK A2

Wireless Microphone

Quick Guide

– Preface

Thank you for choosing the LARK A2 Wireless Microphones.

For detailed information, scan the QR code to access the User Manual available in English and other languages.

EN Please read this Quick Guide carefully before using the product. For detailed information, scan the QR code to access the User Manual available in English and other languages.

FR Veuillez lire attentivement ce guide rapide avant d'utiliser l'appareil. Pour plus d'informations, scannez le code QR pour accéder au manuel d'utilisation disponible en anglais et dans d'autres langues.

DE Bitte lesen Sie diese Kurzanleitung sorgfältig durch, bevor Sie das Produkt verwenden. Für weitere Informationen scannen Sie bitte den QR-Code, um die Bedienungsanleitung auf Englisch und in anderen Sprachen aufzurufen.

IT Leggere con attenzione questa Guida rapida prima di utilizzare il prodotto. Scansionare il codice QR per accedere al Manuale utente disponibile in inglese e altre lingue per informazioni più dettagliate.

ES Lea atentamente esta guía rápida antes de utilizar el producto. Para obtener información detallada, escanee el código QR y acceda al Manual de usuario, disponible en inglés y otros idiomas.

PT Leia atentamente este Guia Rápido antes de usar o produto. Para obter informações detalhadas, leia o código QR para acessar o Manual do Usuário, disponível em inglês e outros idiomas.

— Preface

[KR] 본 제품을 사용하기 전에 반드시 본 빠른 설명서를 읽어 주십시오. 상세한 정보는 QR 코드를 스캔하셔서 영문 및 기타 언어로 제공해 드리는 사용자 설명서를 확인하십시오.


[RU] Перед использованием внимательно изучите данное краткое руководство. Для получения подробной информации отсканируйте QR-код, чтобы открыть руководство пользователя на английском и других доступных языках.

[ID] Silakan baca Panduan Cepat ini dengan cermat sebelum menggunakan produk ini. Untuk informasi lebih lengkap, pindai kode QR untuk mengakses Panduan Pengguna yang tersedia dalam bahasa Inggris dan bahasa lainnya.




- Wearing Method

Mic Wearing




Furry Windshield Installation




How to Connect

LARKA2 Duo




1. Plug the USB-C receiver into your phone. The Mic will automatically power on and connect when taken out from the charging case—simply wear the Mic and start recording.



– How to Connect


LARKA2 Mini Duo



LARKA2 Solo



1. Plug the USB-C receiver into your phone, then press and hold the power button on the Mic for 3s to turn it on. It will pair automatically—simply wear the Mic and start recording.




– Manual Pairing & Connection

Plug the USB-C receiver into your phone, then press and hold its button for 3s to initiate pairing. Next, press and hold the button on the powered-off Mic for 6s to initiate pairing. They will connect automatically.



* Factory pre-paired. If connection fails, try manual pairing.

- Mic



Blue Flash (Slow): Disconnected
Blue Flash (Fast): Pairing
Solid Blue: Connected
Solid Green: Noise Cancellation
Solid Red: Mute


✕1 : Noise Cancellation
✕2 : Mute
✕3 : Start/Stop Recording
3S : Power On/Off
6S : Pair

Identify Mics:

Yellow: Mic 1

Purple: Mic 2

– USB-C Receiver



Blue Flash (Slow): Disconnected
Blue Flash (Fast): Pairing
Solid Blue: Connected
Solid Green: Noise Cancellation
Solid Red: Mute

×1 : Noise Cancellation
×2 : Mic 1 Mute
×3 : Mic 2 Mute
3S : Pair



- App Information

HollyAudio

The HollyAudio App is available for download on Google Play Store and Apple App Store. You can also scan the QR code below to download the app.



The HollyAudio app is a perfect match for Hollyland wireless microphones. With the app, you'll have access to a range of smart features, such as parameter configurations and firmware updates, that work together seamlessly to enhance your microphone performance.



App



Requires Android
8.0 or higher



Requires iOS
12.0 or higher

– Support

If you encounter any problems in using the product or need any help, please contact Hollyland Support Team via the following ways:



Hollyland User Group



HollylandTech



HollylandTech



support@hollyland.com



HollylandTech



www.hollyland.com

Statement:

All copyrights belong to Shenzhen Hollyland Technology Co., Ltd. Without the written approval of Shenzhen Hollyland Technology Co., Ltd., no organization or individual may copy or reproduce part or all of any written or illustrative content and disseminate it in any form.

Trademark Statement:

All the trademarks are owned by Shenzhen Hollyland Technology Co., Ltd.

Note: Due to product version upgrades or other reasons, this Quick Guide will be updated from time to time. Unless otherwise agreed, this document is provided as a guide for use only. All representations, information, and recommendations in this document do not constitute warranties of any kind, express, or implied.

HOLLYVIEW

Powered by Hollyland

Shenzhen Hollyland Technology Co., Ltd.

8F, 5D Building, Skyworth Innovation Valley,
Tangtou Road, Shiyan Street, Baoan District, Shenzhen, 518108, China

Made in China