


Hollyland Headset for the Solidcom C1 HUB Base


Quick Guide

PACKING LIST



Note: The amount of items depends on the configuration of product.


PRODUCT INTERFACES



① Microphone


- Speaker
- ④ Microphone Boom

③ Headset Jack
⑤ Adjustable Headband



3.5 mm Headset Jack Jack Definition: M G R L

PRODUCT INSTALLATION AND USAGE GUIDE



Install Solidcom C1 headset:

- ① Plug the headset into the 3.5 mm port of the HUB Base and rotate the nut clockwise to secure the headset.
- 2 Move the microphone boom down, and you can hear a 'click'. Then you can start to talk.
- ③ If you just want to listen, make the microphone boom upgright. Then, you will hear a 'click' sound. And microphone will mute at the time.

SPECIFICATIONS

Туре	Monaural
Cable Length	Approximately 61" (1550mm)
Frequency Information	Speaker: 100Hz ~ 10KHz Microphone: 100Hz ~ 10KHz
Distortion	< 1%
Microphone Sensitivity	-38±4 dBV @1KHz, 94dBSPL
Microphone Type	Electret (Single-Pointing)
Impedance	Speaker: $32\Omega \pm 15\%$ @1KHz 1mW Microphone: Max. 2.2k Ω
Weight	Approximately 6 oz. (170g)
Working Temperature	0~+45°C (working status) -10~ +60°C (working status)

Safety Precautions

Do not place the product near or inside heating devices including but not limitedt a microwave ovens, induction coakers, electric ovens, electric heaters, pressura cookers, water heaters, gas stoves) to prevent the battery from overheating and exploding. Never use non-original charging cases, cables and batteries with the product. The use of non-original spare parts may cause electric shock, fire, explosion or other dangers.

Support

If you encounter any problems in using the product and need any help, please contact Hollyland Support Team via the following ways:

Hollvland User Group



HollylandTech

(HollylandTech

- HollylandTech
- support@hollyland-tech.com
- www.hollyland-tech.com

Statement: All copyrights belong to Shenzhen Hollyland Technology Co.,LTD.

Trademark Statement:

Without the written approval of Shenzhen Hollyland Technology Co.,LTD, no organization or individual may copy or reproduce part or all of the content of the text without authorization , and may not disseminate it in any form.

organization or individual may copy or reproduce part or all of the content of the textwithout authorization , and may not disseminate it in any form.

Note:

Due to product version upgrades or other reasons, this quick guide will be updated from time to time. Unless otherwise agreed, this document is provided as a guide for use only. All representations, information, recommendations in this document do not constitute warranties of any kind , express or implied.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The device has been tested and comply with FCC SAR limits.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.